

**Document number :** pe91.30-p-2050-97maa  
**Document title :** Electrical function schematic, seat heater (SIH)

Code:	Designation:	Position:
1	Circuit 15, status	6G
1	Circuit 15, status	9K
2	SIH switch, status	5B
2	SIH switch, status	12F
3	Seat heater, request	5E
3	Seat heater, request	10H
4	Seat heater, actuation	3F
4	Seat heater, actuation	12J
5	Seat heater status indication, signal	6D
5	Seat heater status indication, signal	6B
5	Seat heater status indication, signal	11H
5	Seat heater status indication, signal	13F
A8/1	Transmitter key	6K
CAN B	Interior CAN	5H
CAN B	Interior CAN	8K
Code 872	Left and right rear seat heaters	9E
N10	Front SAM control unit	5E
N25/7	HS [SIH], seat ventilation and steering wheel heater control unit	10J
N72/1	Upper control panel control unit	5C
N72/1s10	Left front HS [SIH] switch	5A
N72/1s11	Right front HS [SIH] switch	5A
N72/2	RCP [HBF] control unit	10F
N72/2s10	Left HS [SIH] switch, 2nd seat row	13F
N72/2s11	Right HS [SIH] switch, 2nd seat row	13F
N73	EIS [EVS] control unit	5J
R13/1	Left front seat heated cushion	1F
R13/2	Left front backrest heated cushion	1F
R13/3	Right front seat heated cushion	1F
R13/4	Right front backrest heated cushion	1G
R13/5	Left 2nd row seat heated cushion	13J
R13/6	Left 2nd row backrest heated cushion	13K
R13/7	Right 2nd row seat heated cushion	13K
R13/8	Right 2nd row backrest heated cushion	13K

