


P42.10-0217-01

	Removing, installing		
1	Remove cover below instrument panel		AR68.10-P-1500P
2	Unplug electric connector at stop lamp switch (S9)		
3	Press locking device (S9b).		
4	Turn and pull out stop lamp switch (S9).	<b>i</b> <b>Installation:</b> pull out actuating pin (S9a) completely, adjust if necessary. Push through brake pedal (24), insert stop lamp switch (S9) and turn until locking device (S9b) engages. The actuating path is adjusted automatically.	
5	Install in the reverse order		